

Allgon Timber Treatment for Borers and Termites

FAQ's

Allgon

Q: What are the best application methods for Allgon Timber Treatment?

A: The product can be applied by brush, roller, spraying or dipping



BRUSH



ROLLER



SPRAYING



DIPPING

Q: What container sizes is this product available in?

A: 5 & 15 litre containers.



Q: How do I clean up?

A: Brushes and rollers can be rinsed out in water. No solvents required.



Q: What are the application rates for Allgon Timber Treatment?

A: 0-25 mm depth: 125 mL/m²
 25-50 mm depth: 250 mL/m²
 50-100 mm depth: 500 mL/m²
 Internal treatment: 5 mL/1000 cubic cm

Q: Before applying the product, what preparation do I need to consider?

A: For best results, it is important to apply Allgon Timber Treatment to dry timber, free from excessive dirt, grease, paint or any coatings that may inhibit absorption of the product.

Q: How to enhance the treatment on very dry surfaces?

A: When treating very dry surfaces, the treatment can be enhanced if the surface is sprayed with water 3 to 4 hours prior to applying the product.



Q: How many coats are required for severe infestations?

A: For severe infestations, apply two coatings of Allgon Timber Treatment for Borers and Termites 3 hours apart.

Q: How to improve internal penetration of larger sections of timber structures?

A: To assist in the internal penetration of larger sections of timber structures, drill into the sections every 600 mm with a 5-20 mm diameter hole. Fill with product and stop up ends.



Q: Can I cut timber that has been treated?

A: Yes, treated timber can be cut, notched or drilled.

Q: What nails, screws and fixing should be used with treated timber?

A: Use hot-dipped galvanised coatings for nails, screws and fixings for all outdoor applications. In more extreme conditions or near the coast, stainless steel fixings and connectors should be used. It is also important to design the connections to drain and shed water and to reseal any cut ends.

Q: Will the treated timber corrode metal fittings or fasteners?

A: No, normal steel nails and plates are suitable for use as fixings.

Q: Can I fix hardwood decking over treated timber bearers and joists?

A: Yes, but consult a nail manufacturer's advice. Generally treated timber bearers have good holding power but require longer nails than hardwoods for fixing.

Q: How long does the product take to dry?

A: Up to 3 hours, depending on the density of the timber

Q: How long does the timber treatment last?

A: Allgon Timber Treatment is guaranteed to remain termite resistant for at least 25 years.

Q: How regularly should Allgon Timber Treatment be applied?

A: On average every 3 to 5 years. For best maintenance results, re-apply within 12 months and subsequently every 18 months. If extreme environmental circumstances prevail, retreat when necessary.

