

## Camilleri Under Slab Injection System Installation

1. After viewing the floor plan and determining our plan of attack, measure and mark the place in the sand where we intend to lay the pipe. As the chemical spread each of our pipe will be 250mm, we then need to start our marks 250mm from the end of our footing and then at 500mm centres.
2. Start running out the pipe, making sure that when you peg down, the perforations are pointing uppermost.
3. Seal the innermost end of the pipe by inserting the stopper.
4. Use steel pegs to hold the pipe in place.
5. Leave a little of the pipe protruding under the footings at the outermost end and cut.
6. All pipes laid.
7. When all these pipes are laid, we install our pipe on the wall of the footing trench, making sure in this case that the perforations are pointing in towards where the water vapour membrane would be running and that is, up the footing wall. This pipe, of course, is for the perimeter spray.
8. When this is completed, we connect all of our feeder pipes (pipes with no perforations) to all our inlet points and direct them to the valve box.
9. Connect feeders to hader valve.
10. Place valve box over header and back fill.

