


Goliath[®] Gel

BAIT GUN 345

The design of this applicator utilises negative air pressure to pull bait through the bait gun to ensure control of each bait placement. The sturdy features of this well designed and ergonomic tool make the Goliath[®] Gel Bait Gun 345 convenient and easy to use.



Key

1. Clear application tip
2. Piston
3. Cartridge
4. Hooks
5. Handel
6. Settings
7. Selection button
8. Push Stick
9. Threaded nozzle

To Begin An Application

1. Insert the clear application tip [1], into the threaded nozzle [9] by turning clockwise until finger tight.
2. Adjust the selection button [7] to setting to 1 at the base of the applicator handle. ***This step is important to prime the applicator.***
3. Insert the cartridge [3] into the cartridge chamber by ***gently*** pressing forward and down until the base of the flange end of the cartridge is seated in the hooks [4].

NOTE: During the initial loading process, the cartridge will engage the pumping mechanism of the piston. This may result in the product being pushed into the application tip.*

If the cartridge is inserted into the chamber with force, the bait may be pushed through the application tip which could result in the loss of a minimal amount of product.

*To avoid discharge of product, insert the orange reservoir cap onto the threaded nozzle [9] while you change reservoirs.

Selecting Application Rates

Bait placement size can be selected at the base of the applicator handle [5]. To select the desired application rate, the selection button must be depressed while moving the lever to the desired setting of 1 to 5.

The ideal setting is position 1 which delivers the recommended bait point of 0.05gm.

Trouble Shooting

If the **Goliath Gel Bait Gun 345** will not dispense bait:

- **Goliath Gel Bait Gun 345 may need to be primed**
Adjust the selection button [7] setting to 1 during initial application to prime the applicator. Once it has been primed, the applicator settings can be changed.
- **The cartridge may have an air pocket**
To resolve this issue, leave the cartridge [3] in the **Goliath Gel Bait Gun 345** and insert the push stick [8] provided into the end of the cartridge [3]. Gently push to advance the bait and remove the air pocket. Once the air pocket is eliminated, the bait will flow through the piston evenly.

Cleaning

Routine cleaning of the Goliath Gel Bait Gun 345 when used with Goliath cockroach gel bait should not be necessary due to the unique formulation of this cockroach gel bait.

If bait other than **Goliath** is used with this applicator, the various bait formulations remaining in the piston could dry and block the flow of bait for the next application. If this occurs, use a mild detergent and water solution to clean all components.

Changing Cartridges

To remove the cartridge [3], select **before** setting 1 [7]. Gently push the cartridge flange forward and up until the cartridge is free of the hooks [4].

Goliath Gel Bait Gun 345 applicator will maintain some bait in the piston and tip, even when the cartridge is empty or removed.

When the gun will not be used for several days, it is recommended that the bait be cleared from the piston by removing the empty cartridge [3] and manually pressing the piston with the push stick [8].

NOTE: The piston and tip holds approximately 1.5 grams of bait.

TIP: The orange cap from the Goliath cartridge should be placed on the threaded nozzle to avoid losing bait during transportation or cartridge replacement.